

# Office Caddy



## REQUIREMENTS

1, 800g Can, top removed.  
Jeans, 17 cm off the  
bottom of 1 leg.  
Upholstery thread  
Fabric Glue or Hot Glue Gun

1. Select a pair of jeans with a larger circumference cuff than the can you are using for the caddy.
2. Cut the leg of the jeans off 7 cm longer than the can.
3. Design & attach 1 or 2 pockets using top stitch in a contrasting thread. Picture 1 (Make sure the top of the pocket is towards the hem)
4. Reduce the diameter of the leg, to fit the can snugly, by stitching 2 cm pen pockets the length of the leg. (Picture 2)
5. Position the jeans so the hem is covering the rim of the can.
6. Turn upside down & using double upholstery thread & running stitch sew around the edge. (Picture 3)
7. Pull tightly and tie securely. Glue into place with PVA or hot glue gun.



Picture 1



Picture 2



Picture 3